

# Smoke Alarm Tenant Tips



## Why do smoke alarms false alarm?

Here are some factors to consider if a smoke alarm is beeping and how to fix it.

### POWER ISSUES



Power issues can cause the smoke alarm to activate. Unstable power or power interruptions can cause electrical spikes in the circuit, this may cause the smoke alarm to beep or alarm for a short period of time.

**Tenant Tip.** Wait for the power surges to finish as the smoke alarms should reset. You could also try resetting the power by turning the lighting circuit on and off in the electricity box.

### AIR MOVEMENT



High air movement can cause the smoke alarm to false alarm.

**Tenant Tip.** Ensure that portable fans, heaters, radiators and air conditioning ducts are away from smoke alarms.

### RIPPLE FREQUENCY



In some areas of Southern Queensland, Central Coast NSW and Sydney, electricity suppliers are injecting an off-peak signal onto the network to remotely control devices like hot water systems and street lighting. These ripples usually occur in the early hours of the morning and can cause smoke alarms to beep or activate.

**Tenant Tip.** Take note of the times this is happening. If this beeping is occurring at a similar time each day/night this could be the cause.

### HIGH HUMIDITY



High humidity could be causing the smoke alarm to false alarm. Water vapours can develop inside the smoke sensor causing smoke alarms to react the same way as it does smoke. Once humidity reaches 85%, false alarms could frequently occur.

**Tenant Tip.** In high humidity, use a hair dryer to blow warm air through the smoke alarm to assist with drying out any moisture build up.

### TENANT SUPPORT



If you are still experiencing issues

#### During Business Hours

Contact your Property Manager or 1300 Smoke Alarms on 1300 766 532

#### After Hours

Contact 1300 Smoke Alarms on 0414 708 871 or [www.1300smokealarms.com.au/tenant](http://www.1300smokealarms.com.au/tenant) for more information

### INSECTS AND DUST



Insects and dust are a common cause of false alarms.

**Tenant Tip.** You can clean/vacuum your smoke alarm to remove any loose dust or dirt that may be inside the unit. You could spray the base plate area using insect repellent or wipes to deter insects (do not spray directly at alarm)

### STEAM



Steam from bathrooms and laundry can cause a smoke alarm to activate.

**Tenant Tip.** Alarms that are located close to bathrooms and laundries can false alarm. Ensure you close bathroom doors when showering and laundry doors to avoid the steam and humidity triggering off the alarms.

### COOKING FUMES



Cooking fumes can cause a smoke alarm to activate especially when the smoke alarm is located too close to the kitchen.

**Tenant Tip.** Alarms that are sensitive to cooking fumes and toasters can be a real issue. Try moving the location of the toaster, use the exhaust fan when cooking and/or open windows and doors. Use the hush button on the alarm to disable for 10 minutes until the cooking fumes disappear.

### WEAK BATTERIES



Weak batteries will cause beeping and increase the chance of false alarms.

**Tenant Tip.** If this occurs during a tenancy, replace with a new battery. Always use good quality, reliable batteries and ensure that they are inserted the correct way with firm contact on the battery terminals.